



Mirror head adjusts
to horizontal or
verticle position

MADE IN TAIWAN

INSTALLATION INSTRUCTIONS

1. Adjust mirror arms so they fit your vehicle mirror.
2. Size rubber strap with quick release adjuster clip.
3. Stretch strap around vehicle mirror and hook to mirror arm.
MAKE SURE RUBBER STRAPS ARE VERY TIGHT.
4. Adjust mirror head for desired visibility
5. Periodically check that mirror is securely attached.
6. Remove "CLIP ON MIRROR" when not towing.

Replacement straps are available seperately,
Part # 30-0098

PRIME PRODUCTS,PARAMOUNT,CA 90723