

Common mistakes when renting a wall paper steamer

- Fully read operator's manual before operating.
- The water is heated with a electric heating element. To reduce heat up time put hot water in the tank, not cold water.
- Be aware there are two basic types of wall paper. Vinyl and paper. If using this with vinyl we would highly recommend renting a wall paper perforator. Steam cannot pass through vinyl, the perforator creates holes in the wall paper to allow the steam pass through.
- Do not overfill. The steam is generated in the water tank. If the water tank is filled to the top with water there is no place for the steam to be generated. So, I suggest to fill half way on the site glass on the opposite side of the switch.
- The frame of the steamer works as a stool!
- We have seen the wires from these units get pulled out and partially disconnected several times by someone trying to move the steamer over by pulling the cord. Please, do not do this!
- Remove all water from the tank before returning please.

Thank you and good luck!