Soft Serve Machine Quick Setup Instructions

Machine must be on a dedicated 20 AMP circuit.

Damage will occur to the machine's compressor if another appliance shares the same circuit. No extension cords can be used with machine. Refer to operator's manual for any other questions. Do not adjust the consistency control; additional fees will be applied to your credit card.

Setup Instructions

- 1. Place empty cup under spicket
- 2. Pour mix in hole in hopper & pull down spicket
- 3. Fill cup half full of mix and discard
- 4. Fill hole in the hopper until it is full
- 5. Place carburetor tube in hole (in closed position)
- 6. Turn switch to cleanout position wait 2 seconds for the audible click then quickly switch it to auto position
- 7. Wait about 15 to 20 minutes until compressor stops
- 8. Open carburetor tube to large hole. Fill hopper throughout the day as needed

Clean Up

- 1. Remove the carburetor tube
- 2. Place in cleanout position and drain out all of product
- 3. Fill hopper with warm soapy water and place in cleanout for about 2 minutes
- 4. Drain out in cleanout position
- 5. Repeat with just cold water